

ORDER NO. ARP1516

COMPACT DISC PLAYER

PD-5100 PD-4100

MODELS PD-5100 AND PD-4100 HAVE SEVEN VERSIONS:

-		Applicable	model		Power requirement	Export destination
Туре	PD-5100	PD-5100-S	PD-4100	PD-4100-S		EXPORT GOSTINETION
KU	0	-	0	-	AC120V only	U.S.A
KC	0	_	0	-	AC120V only	Canada
HEM	0	0	0	0	AC220V,240V (switchable) *	European continent
HB	0		0	0	AC220V.240V (switchable) *	United kinglom
SD	0	-	0	_	AC110V.120 - 127V,220V,240V (switchable)	Kingdom of Saudi Arabia and General market
SD/G	0	_	_	_	AC110V,120 - 127V,220V,240V (switchable)	U.S.Military
HP	0	*	0	-	AC220V,240V (switchable) *	Australia

* Change the position of jumper of the Transformer board assembly.

- This service manual is applicable to the KU, KC, HEM and HB types.
- ●For the PD-5100/KC, HEM and HB types, please refer to pages 76.
- •For the PD-4100/KU, KC, HEM and HB types, please refer to pages 8).
- For the PD-5100-S/HEM, PD-4100-S/HEM and HB types, please refer to pages 105.
- •For the PD-5100/SD,SD/G and HP types, refer to the additional service manual.
- •For the PD-4100/SD and HP types, refer to the additional service marual.
- Ce manuel pour le service comprend les explications en français de réglage.
- Este manual de servicio trata del método ajuste escrito en español.

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A. PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 2740 Beveren, Belgium

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 58-99 11

IFA© MAR 188 Printed in Japan



CONTENTS

1. General

1.	SPECIFICATIONS2	9
2.	SAFETY INFORMATION 3	
3.	PANEL FACILITIES5	
4.	EXPLODED VIEWS AND PARTS LIST 8	10
	PACKING14	11
6.	P.C.BOARDS CONNECTION DIAGRAM18	12
	SCHEMATIC DIAGRAM 21	
8.	ELECTRICAL PARTS LIST29	13

9. ADJUSTMENTS31
RÉGLAGE 45
AJUSTE 61
10. REMOTE CONTROL UNIT75
11. FOR KC, HEM AND HB TYPES76
12. FOR PD - 4100 / KU, KC, HEM
AND HB TYPES 89
13. FOR PD - 5100 - S/HEM,
PD - 4100 - S / HEM AND HR TYPES 105

1. SPECIFICATIONS

3. Functions

- Play
- Pause
- Manual search
- Programmed playback
- Track search
- Programmed repeat
- Pause program
- Direct track search
- Direct programming
- All track repeat
- Add-on program
- Auto programmed editing
- Random play

The above functions can be operated with the remote control unit.

Timer start

4. Accessories

•	Remote control unit	1
•	Size AAA/RO3 dry cell batteries	2
•	Output cable	1
•	Operating instructions	1

NOTE:

The specifications and design of this product are subject to change without notice, due to improvements.

2. SAFETY INFORMATION


-(FOR USA MODEL ONLY)-

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120 V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a $\underline{\mathbb{A}}$ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

-(FOR EUROPEAN MODEL ONLY)-

VAROITUS! -

LAITE SISÄLTÄA LASERDIODIN, JOKA LAHETTAA NAKYMATONTA, SILMILLE VAARALLISTA INFRAPUNASÄTEILYA LAITTEEN SISALLA ON LASERDIODIN LÄHEISYYDESSA KUVAN 1. MUKAINEN VAROITUSMERKKI.



LASER Kuva 1 Lasersateilyn varoitusmerkki

WARNING!-

DEVICE INCLUDES LASER DIODE WHICH EMITS INVISIBLE INFRARED RADIATION WHICH IS DANGEROUS TO EYES. THERE IS A WARNING SIGN ACCORDING TO PICTURE 1 INSIDE THE DEVICE CLOSE TO THE LASER DIODE.



LASER
Picture 1
Warning sign for laser radiation

----- IMPORTANT -

THIS PIONEER APPARATUS CONTAINS LASER OF HIGHER CLASS THAN 1. SERVICING OPERATION OF THE APPARATUS SHOULD BE DONE BY A SPECIALLY INSTRUCTED PERSON.

ADVERSEL: -


USYNLIG LASERSTRÄLING VED ÄBNING NÄR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION UNDGÅ UDSAETTELSE FOR STRÅLING.

VIKTIGT

APARATEN INNEHÅLLER LASER AV HÖGRE KLASS ÄN 1. INGREPP I APPARATEN BÖR GÖRAS AV SPECIELLT UTBILDAD PERSONAL.



LABEL CHECK



HB model

CAUTION
INVISIBLE LASER
RADIATION WHEN OPEN,
AVOID EXPOSURE
TO BEAM PRW1018

HEM model

CAUTION
LASER RADIATION WHEN DRIN, AVOID EXPOSURE TO BEAM
ADVANSEL
FARE FOR USYNLIG LASERSTRÂLING VED ÂBHING AF DARSEL
UNDGÂ AT UDSÆTTE BJIRRE FOR ISTRÂLING.
VORSCHT!
UNSCHTBARE LASER STRAMLING TRITT AUS, WENN DECKEL
LOOER KLAPPE GEOFFIET IST! NICHT DEM STRAM, AUSSETZEM
PRW-175

ADDITIONAL LASER PRECAUTIONS

1. Laser Interlock Mechanism

The clamp switch (S102) detects the completion of the Load in operation, and the ON/ OFF status of the clamp switch is in turn detected by the microcomputer. The laser diode is designed not to oscillate while the clamp switch is in OFF status.


Consequently, if S102 is accidentally short-circuited, the interlock mechanism will become incapable of operation.

Moreover, when short-circuiting occurs between Pins 4 or 5 of CXA1081S (IC 1) and GND, or between Pin 29 of CXA1081S (IC 1) and GND, or between the terminals of Q1 (a Fault Condition will occur in all three cases), the laser diode will oscillate continuously. Note that during TEST Mode (see page 31), the interlock mechanism does not operate.

2. While the bonnet is in opened status, if the pickup is positioned to allow direct visibility of the objective lens at the outer periphery from the outer diameter of the disc clamper (80-mm diameter), the pickup can be flooded with radiation of more than class 1 of the laser optical system during any Fault Condition in Item 1 above or during TEST, Mode.

3. PANEL FACILITIES

FRONT PANEL



track to indicate division of the tracking separate

tunes and items of music.

pressed.



RANDOM PLAY key

Press to begin random playback.


OPEN/CLOSE key (▲)

Press when you wish to eject or load a disc. Each time the key is pressed, the tray is alternately pushed out or pulled in.

TIME key

This key selects the display mode of the indicator panel.

Each time the key is pressed, the indication changes from TIME, REMAIN, to TOTAL in that order. (For details concerning the display contents, refer to the explanation about the indicators.)



REPEAT key

Press to perform repeat playback

- If pressed during normal playback mode, all tracks on the disc will be repeatedly played back.
- If pressed during programmed playback, the programmed tracks will be repeatedly played back in the programmed order.
- In the case of random play mode, after all the tracks have been played, random play will start again.

PROGRAM MEMORY key


Use to program a sequence of tracks.

 Press this key after selecting a desired track with the track number keys. Tracks will be added to the program in the order in which they are selected.


AUTO PROGRAM EDIT key

Press to program a tune which may be played back within a specified time.

REAR PANEL



REMOTE CONTROL UNIT



TRACK SEARCH keys

During normal playback, programmed playback or pause modes, these keys are pressed to search for the desired track. Pressing either key causes the player to advance to the next track or to return to the previous track. Even in stop mode, these keys can be used to select the desired track. Press the PLAY key to playback the desired track.

- [>> I : When pressed once, playback advances to the beginning of the next track on the disc; when pressed continuously, playback advances to the beginning of succeeding tracks on the disc. (During programmed playback, it advances to the beginning of the next programmed track.)

STOP/CLEAR key ()


Press to stop playback. When pressed, the player goes into stop mode and all operations stop. Press to clear a program. When pressed during stop mode, the program stored in memory is cleared.

PAUSE key (III)

Press to temporarily interrupt playback. When pressed again, the pause mode is cancelled and playback resumes.

PLAY key (►)

Press to begin playback, and to cancel the pause mode.



MANUAL SEARCH keys

When the player is in playback or pause modes, these keys are pressed to perform fast forward or reverse operations to allow manual searching. These operations are only carried out during the time either key is pressed.

- [>>]: For fast forward operation. If the end of the disc is reached during fast forward operation, "End" will be displayed and the player will enter the pause mode. [During programmed playback, the player will enter the pause mode right before it reaches the next track (program step).]
- [◄]: For fast reverse operation. If the beginning of the disc is reached during fast reverse operation, the player will enter the playback mode. [During programmed playback, the player will enter the playback mode right before it reaches the previous track (program step).]

PHONES (headphones) jack

Remote sensor

When you wish to use headphones, insert the plug for the headphones into the headphone jack.

PHONES LEVEL control knob

Use to adjust the level of sound when using headphones. Turning the knob to the right in creases the sound level.



4. EXPLODED VIEWS AND PARTS LIST


NOTES:


- Parts without part number cannot be supplied.
- •The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.
- ** GENERALLY MOVES FASTER THAN *
- This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.
- Parts marked by "O" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

4.1 Exterior

Parts List of Exterior

Mark N	No.	Part No.	Description	Mark	No.	Part No.	Description
Δ	1	CM-22C	Strain relief		101	,	Under base
Δ	2	PDG1015	AC power cord		102		
$\overline{\Lambda}$ \star	3	PTT1054	Power transformer		103		Rear base
_ ~	_		(AC120V)		104		Angle
	4	PBA1001	Screw		105		Panel angle
	5	PNW1376	Insulator		106		Board angle
	6	PAC1208	Headphone knob		107		Switch angle
	7	PAC1244	Button A (PLAY)		108		Slide guide
	8	PAC1246	Button A (POWER)		109		Mechanism support
	9	PAC1247	Button A		110		P.Plate holder
	10	PAC1248	Button B		111		Loading base assembly
	11	PAC1250	Button B (O/C)		112		Tray assembly
	12	PAM1230	FL filter A		113		
	13	PAM1175	Window B		114		Headphone name plate
	14	PNW1356	Function panel B		115		Name plate
	15	PNW1358	Name plate B (tray)		116		SW joint
	16	BBZ30P060FMC	Screw		117		Headphone board assembly
	17	BBZ30P080FZK	Screw	Δ	118		Transformer board
	18	BBZ30P120FMC	Screw				assembly
•	19	BBZ30P230FMC	Screw				
	20	FBT40P080FZK	Screw				
	21	IBZ40P080FCC	Screw				
	22	PMZ30P060FCU	Screw				
\odot	23	PWZ1419	Main board assembly				
\odot	24	PWZ1425	Function board assebmly				
	25	PYY1063	Servo mechanism assembly				
	26	PYY1062	Bonnet				





5. PACKING

<u>Mark</u>	No.	Part No.	Description
		PDE1002 (PDE1001)	Connection cord with pin plug
	2	PHL1002 PRB1045	Sheet Operating instructions
			(Englesh)
	4	PHA1059	Protector (L)
	5	PHA1060	Protector (R)
	7	PHG1179 PWW1022	Packing case Remote control unit
	8	PHC1030	Spacer (into the tray)
	51		Battery $(UM - 4)$
			6
	/		
<			
			3
		1	
		1	
	300		
	1		
		100	
		$\mathcal{I}_{\mathcal{I}}$	
			5
			2
			8
		7	Pa
			`4
			(51)

Parts List of Mechanism section

Mark	No.	Part No.	Description	Mark	No.	Part No.	Description
	1	PBH1013	Spring		29	PWY1003	Pick up assembly
		PBP-001	Steel ball ϕ 4		30	PYY1063	Servo mechanism assembly
		PEB1032	Stopper rubber		31	PYY1028	Clamper assembly
	-	PNW1084	Clamp holder		32		Plate spring
	5	PNW1085	Clamp retainer			PNW1329	Disc plate
	6	PBH1012	Clamp spring		34	PNW1390	Tray
**	_	PEB1013	Belt (LOADING)			PNW1331	Plate lever (R)
××	-	PNW1069	Loading base			PNW1332	Rack
	-	PNW1083	Clamp lever				Plate lever (F)
	_	PNW1083 PNW1171	Gear pulley		38	BPZ20P080FZK	Screw
**	11	VSK-015	Leaf switch (CLAMP,S102)		39	PBA1025	Screw
		PYY1025	Motor assembly		40	PBA1001	Screw
* *	12	1 1 1 1020	(CARRIAGE, LOADING)		41	PMZ20P030FMC	Screw
	12	PBH1009	Earth spring		42	PPZ30P080FMC	Screw
		PMM1010	Disc cushion		43	IPZ30P060FMC	Screw
	15	CGDYX104M25	Semiconductive ceramic		44	BBZ30P230FMC	Screw
	13	CGDTATO4NIZS	capacitor		45	PEB1031	Floating rubber
	10	PBA - 209	Screw M2 × 3			PXM1002	Motor
		PBH1008	Drive spring				(CARRIAGE, LOADING)
		PBK1010	Plate spring				(0:220:02)
	10	PBKIUIU	riate spring		101		Tray assembly
	10	DED1072	Belt (CARRIAGE)		102		Loading base assembly
**		PEB1072			103		Magnet
		PLA1003	Drive worm		104		Clamper
		PLA1004	Guide bar		105		Slide base
		PNW1062	Mechanism chassis		100		Share base
	23	PNW1063	Carriage plate		106		Ballast base
		D177711001	D' - Ashi-		107		Gear shaft
		PNW1064	Disc table		108		Motor pulley
		PNW1066	Pulley		109		· · · · ·
**		PSH1003	Slide switch (INSIDE,S101)				Earth lead unit
**		PXM1001	Spindle motor		110		Earth lead that
	28	BBZ30P080FCC	Screw		111		Pose plate
					111		Base plate
					112		Cloth tape
					113		Carriage M board



No.	Oscilloscope Setting H	Test Points	Adjusting Points	Check items / Adjustment specifications	Adjustment procedure
5 Gra	ting Adjus	tment (2) (us	ing discs with a	recording time of	60 min. or more)
0.5V div	/ Sms / div	TP1 Pin 2 (TRKG. ERR) TP1 39k 0.001 µ F=	9-9 Grating Grating	rating adjustment crew isc Null point Maximum amplitude	Note: This adjustment can only be performed with a dishaving pits up to R115mm not with the Test Disc (YEDS-7). Put unit in the test mode (see page 31). Load the test disc, move the pickup to the outer periphery so that the pickup grating adjustment hole is visible from the pit surface of the disc or from the hole in the servormechanism (see Fig. 9-9). Press the TRACK FWD key (▷) and PLAY key (▷) in sequence to close the focus servo and spindle servo (do not turn on the tracking servo). Observe the TRKG.ERR (tracking error) waveform at TP1 pin 2 on an oscilloscope, inserting a 4 kHz low-pass filter (see Fig. 9-10). Insert a ⊕ screwdriver into the grating hole, turn and find the null point (see Photo 9-1). Next, slowly turn the ⊕ screwdriver COUNTERCLOCKWISE from the null point and adjust until the waveform (tracking error signal) reaches maximum amplitude (see Photo 9-3). Note: Use caution since inserting the ⊕ screwdriver forcefully will cause the pickup unit to float upward. Lastly, make sure that there is no major fluctuation in the pp voltage of the tracking error signal (do not insert the cutoff 4 kHz low-pass filter) when the pickup is moved to the outer periphery. If there is a difference of more than ± 10 % again turn the grating adjustment screw and adjust the tracking error signal to maximum.




Photo 9-2 This is not the null-point waveform.




Photo 9-1 Null point





Photo 9-3 Maximum amplitude





Step No.	Oscill Setti	oscope ng	Test Points	Adjusting Points	Check items / Adjustment	Adjustment procedure
NO.	V	200ns	TP1 Pin 1 RF output	Tangential adjustment screw	Sharpest possible eye pattern	 Press the TRACK FWD (▷▷), PLAY (▷), and PAUSE (᠓) keys sequentially to close the all servos (pause indicator will illuminate). Observe TP1 pin 1 (RF output) on the oscilloscope and adjust the tangential adjustment screw to achieve the sharpest possible eye pattern. The point to which the adjusting screw should be set lies about halfway between the points at which the eye pattern becomes most blurred when the screw is rotated clockwise and counterclockwise. When the whole waveform becomes clear, concentrate on sharpening the fine lines forming the diamond at the center of the eye pattern (see Photo 9-8). Adjust until the fine lines on all four sides of the diamond are both sharply defined and dense, as shown in Photo 9-6.
						TP1 Pin 1 (RF) Pin 4 (GND) Fig. 9-12 Note: Use a hex wrench to raise the pickup somewhat while making this adjustment.




Photo 9-6




Photo 9-7




Photo 9-8





Photo 9-9


Step No.	Oscilloscope Setting V H	Test Points	Adjusting Points	Check items / Adjustment specifications	Adjustment procedure
8	Focus gain adju	ıstment			
	20mV/div CH1(X), 5mV/div CH2 (Y) (prove 10:1)	X-axis TP1 Pin 5 (FOCS. IN) Y-axis TP1 Pin 6 (FOCS. ERR)	VR3 (FOCS. GAN)	Phase difference of 90° TP1 Pin 5 (FCS.IN) Pin 4 (GND) Pin 6 (FCS.ERR)	 With the oscillator power turned OFF, connect the oscilloscope and oscillator as shown in Fig. 9-13. Put unit in the test mode (see page 31). Press the TRACK FWD (⋈), PLAY (⋈), and PAUSE (⋈) keys sequentially to close the focus, spindle, and tracking servos. Turn ON the power to the oscillator and set it to output a 1.2kHz 1Vp-p signal. Note: Some oscillators discharge a DC voltage when turned on. It is therefore recommended that the oscillator be connected after it has been turned on. Adjust VR3 FOCS.GAN (focus gain) so that the Lissajous's figure becomes a horizontal circle (phase difference of 90°). 100kΩ (10:1) 100kΩ (10:1)



Gain overcompensated Photo 9-10



Gain optimal Photo 9-11



Gain undercompensated Photo 9-12

Step No.	Oscilloscope Setting	Test Points	Adjusting Points	Check items / Adjustment specifications	Adjustment procedure
	V H			- Specifications	
9	50mV / div CH1 (X), 5mV / div CH2 (Y) (prove 10 : 1)	X-axis TP1 Pin 3 (TRKG. IN) Y-axis TP1 Pin 2 (TRKG. OUT)	VR4 (TRKG.GAN)	Pin 3 (TRKIN) Pin 4 (GND) Pin 2 (TRKERR) 39kΩ	(10 : 1)
	Gain overcom Photo 9	-		Sain optimal Photo 9-14	Gain undercompensated Photo 9-15

Step No.	Oscil Setti	loscope ng	Test	Points Adjusting Adjustment	Check items / Adjustment	Adjustment procedure			
	V	Н	Points	romts	specifications				
10	VCO free-run adjustment								
			TP2 Pin 2	VR8 (VCO.ADJ)	4.275 ± 0.025MHz	 Put unit in the test mode (see page 31). Short the ASY and GND jumper with a screwdriver or similar tool (see Fig. 9-15). Connect a frequency counter capable of measuring frequencies of 10MHz and above to TP2 pin 2. Adjust VR8 (VCO adjust) so that the frequency counter reading becomes 4.275 ± 0.025 MHz. 			
11	Method	for con	firming focu	us error					
			TP1 Pin 6 (FOCS. ERR)			 Put unit in the test node (see page 31). Ground TP1 pin 5 FOCS. IN (focus in) to GND. Observe the waveform output by TP1 pin 6 FOCS. ERR (focus error) when the TRACK FWD (▷) key is pressed. 			







Fig. 9-15 ASY and GND Jumper position







8. ELECTRICAL PARTS LIST

NOTES:

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The ∆mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.
- ★★ GENERALLY MOVES FASTER THAN★

This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.

- When ordering resistors, first convert resistance values into code form as shown in the following examples.
- Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω→56 × 10 ¹ →561	RD1/4PS561J
$47k \Omega \rightarrow 47 \times 10^3 \rightarrow 473$	RD1/4PS4173J
0.5 Ω → 0R5 ···································	RN2H 0 R 5 K
1 Ω→010	

Miscellaneous Parts

Main board Assembly (PWZ1419)

(MTZ5.1C)

1SR139-100

WL02-5004-L

Mark	Symbol & Description	Part No.	SEMI	CONDUCTORS	
Δ	Transformer board assembly		Mark	Symbol & Description	Part No.
•	Main board assembly	PWZ1419			
	Headphone board assembly		**	IC1	CXA1081S
•	Function board assembly	PWZ1425	**	IC2	CXA1082AS
				IC3	CXD1135QZ
Δ	AC power cord	PDG1015		IC4	CXK5816PN-12L
	Power transformer (120V)	PTT1054	~ ~ ~		(CXK5816PN-15L)
$\overline{\Lambda}$	Strain relief	CM-22C			(LH5116-15)
	Pick up assembly	PWY1003	**	IC18	LC7881-B
**	Spindle motor	PXM1001		IC10	M51957AL
~ ~	opinio motor	111111001		IC24,IC25	M5218P
++	Motor assembly	PYY1025	\$\$		NJM78L12A
~ ~	(CARRIAGE, LOADING)	1 1 1 1025	$\triangle \overleftrightarrow{\star} \overleftrightarrow{\star}$		NJM78M05FA
44	S101 Slide switch (INSIDE)	PSH1003		ICII	M 160MONTM
	S102 Leaf switch (CLAMP)	VSK-015	44	IC14	NJM79L12A
~ ^	Side Lear switch (CLAWI)	V3R-015	Δ★★		NJM79M05FA
				IC28	PD0034
A T	ransformer board Asser	mbly	**		PD4151B
2:3	ansionner board Asser	noiy	Δ * *		
				IC11	TA8410K
SWIT	CH			011	DT 4 124EC
Monto	Combal 9 Description	Dona No.	**		DTA124ES
Mark	Symbol & Description	Part No.	**		DTC124ES
	COOL Dark - State (DOUBED)	DC 4 000	**		2SA1048
小本本	S301 Push switch (POWER)	PSA-009		Q1,Q3,Q5	2SA1399
			**	Q21	2SA 854S
CAP	ACITOR			00.00.010.015.005	
		D . 41		Q8,Q9,Q16,Q17,Q27	2SC1740S
Mark	Symbol & Description	Part No.	**		2SC1741S
				Q2,Q4	2SC3581
Δ	C301 (0.01 μ F)	RCG-009		Q13,Q14	2SD1302
			*	D11	MTZ27B
	· · · · · · · · · · · · · · · · · · ·	•			(MTZ27C)
	·		*	D12	MTZ5.1B

△ ★ D25

为 ★ D5 - D10

SEMICONDUCTORS SWITCH Part No. Mark Symbol & Description Part No. Mark Symbol & Description PSG-065 ★★ IC401 M5218L ★★ S1 Tact switch (TEST) **CAPACITORS CAPACITORS** Part No. Mark Symbol & Description Part No. Mark Symbol & Description CCCCH270J50 C401.C402 C95,C96 CEAS330M16 CCCCH300J50 C403,C404 C2 - C4CKCYF103Z50 C145.C146 CCCSL101J50 C405 CKCYF473Z50 CCCSL221J50 C161 **RESISTORS** C40 CEANP4R7M25 Mark Symbol & Description Part No. C85 CEASR33M50 C16,C22 CEAS4R7M50 ★ VR401 Variable resistor PCS1001 (PHONES LEVEL) C34 CEAS4R7M50 R401 - R408 C10.C43,C62,C65 CEAS101M10 RD1/6PM CCC ! C87,C88 CEAS101M50 **OTHERS** C104,C105 CEAS102M25 Mark Symbol & Description Part No. C71,C72,C89,C90,C93,C94,C118 CEAS220M50 C100,C101 CEAS222M16 JA2 Phone jack (PHONES) **RKN1001** CEAS3R3M50 C48 C102,C103 CEAS471M10 Function board Assembly (PWZ1425) C106.C107 CEAS471M16 C5.C7.C12.C15.C19.C20.C23. CEAS330M16 **SEMICONDUCTORS** C25,C26,C28,C36,C38,C41,C47, C50,C59,C60,C69,C70,C79,C80, Mark Symbol & Description Part No. C97.C98 ★ D201 - D206 1SS254 C163 CKCYF473Z50 **SWITCHES** C86.C140 - C144.C301 - C309 CKCYF103Z50 C33,C51 CQMA102K50 Mark Symbol & Description Part No. C14.C17.C46.C61.C63, C147 CQMA103K50 C31,C32,C35,C39 ★★ S201 - S223 Tact switch CQMA104K50 PSG-065 STOP, PAUSE, PLAY, TIME. C29 CQMA272J50 REPEAT, OPEN/CLOSE. C13 CQMA332J50 MANUAL SEARCH, TRACK C9,C11,C21 CQMA333K50 SEARCH, TRACK NO. (0-9) C75,C76 CQMA561J50 RANDOM PLAY, EDIT, PROGRAM MEMORY C1,C27,C49,C73,C74 CQMA472J50 RESISTORS C67,C68 CQMA683J50 C77,C78 CQMA681J50 Mark Symbol & Description Part No. C121.C122 CQSA102J50 R201 - R204 RD1/4PM103J **RESISTORS OTHERS** Mark Symbol & Description Part No. Mark Symbol & Description VR2 Semi-fixed (10k) VRTB6VS103 VR3 - VR7 Semi-fixed (22k) VRTB6VS223 ★ V201 Fluorescent indicator tube PFL1019 VR8 Semi-fixed (1k) VRTS6VS102 IR sensor unit GP11150V R30 Metal thin film RN1/6PQ3601F RD1/6PM COULT Other resistors **OTHERS** Mark Symbol & Description Part No. JA1 2P terminal (OUTPUT) PKB1009 X3 Crystal resonator PSS-012 X1 Ceramic resonator VSS1014

Headphone board Assembly

9. ADJUSTMENTS

The adjustments for this unit are given below. Adjustments must be made in the order in which they are listed.

ADJUSTMENTS AND CHECK ITEMS

- Tracking offset, focus offset and RF offset adjustment
- 2. RF level adjustment
- 3. LD (laser diode) power check
- 4. Focus lock and spindle lock check
- 5. Grating adjustment
- 6. Tracking balance adjustment
- 7. Tangential adjustment
- 8. Focus gain adjustment
- 9. Tracking gain adjustment
- 10. VCO free run frequency adjustment
- 11. Method for confirming S character

REQUIRED EQUIPMENT

- 1. Dual trace oscilloscope
- 2. Optical power meter
- 3. Test disc (YEDS-7)
- 4. Loop gain adjustment filter
- 5. Signal generator
- 6. Frequency counter
- 7. Other regular measuring equipment

Adjustment Point

ABOUT THE TEST MODE

All adjustments must be carried out with the unit in the test mode.

How to activate and release the test mode

- ① To activate the test mode, turn ON the power switch (S301) with the test mode switch (S1) in the ON position.
- ② The test mode is released by turning the power switch OFF.

The functions of the keys in the test mode are outlined in Table 9-1.

ADJUSTMENT VRs AND THEIR NAMES

VR1: Laser power

VR2: RF offset (RF.OFS)

VR3: Focus gain (FOCS.GAN)


VR4: Tracking gain (TRKG.GAN)

VR5: Tracking balance (TRKG.BAL)

VR6: Focus offset (FOCS.OFS)

VR7: Tracking offset (TRKG.OFS)

VR8: VCO adjust (VCO.ADJ)






In the test mode, the servos must be closed and opened individually. Consequently, the servos must each be closed in the proper sequence (serial sequence) in order to put the machine into the play mode. Note also that the machine will not enter the play mode when the PAUSE () key is pressed.

For example, in order to change from the stop to the play mode, the function keys must be pressed in the following order.

* In the test mode, the servos must be operated in serial sequence.



KEY FUNCTIONS IN THE TEST MODE

Symbol	Key name	Function in test mode	Description	
DO	TRACK FWD	Focus servo close	Turns ON the laser diode, and raises and lowers the focusing actuator to close the focus servo.	
\triangleright	PLAY	Spindle servo close	Closes the servo in the CLV-A mode after kicking the spindle motor.	
00	PAUSE	Tracking servo close/open	Acts as a toggle: closes the tracking servo and activates play mode when pressed (provided the focus and spindle servos are closed), at which time the PAUSE indicator illuminates; opens the tracking servo when pressed again.	
DD	MANUAL SEARCH REV	Carriage reverse (moves inward)	Moves carriage quickly (3cm/s) toward innermost track. Be careful not to move too far as there is no safety device to stop the carriage.	
₩	MANUAL SEARCH FWD	Carriage forward (moves outward)	Moves carriage quickly (3cm/s) toward outermost track. Be careful not to move too far as there is no safety device to stop the carriage.	
0	STOP	Stop	Stops all servos and returns system to its initial state.	
A	OPEN/CLOSE	Disc tray open/close	Opens and closes the disc tray. However, pickup does not return to rest on OPEN, and it remains stationary on CLOSE.	

Table 9-1.

Step	Oscilloscope			Check items /			
No.	Setting V H	Test Points	Adjusting Points	Adjustment specifications	Adjustment procedure		
1	Tracking offset	, focus offse	et and RF offset	adjustment	•		
		TP1 Pin 2 (TRKG. ERR)	VR5 (TRKG. BAL) VR7 (TRKG. OFS)	Tracking offset 45° 0V ± 50mV	 Put unit in the test mode (see page 31). Set VR5 TRKG. BAL (tracking balance) to the position about 45° to the left of center. Adjust VR7 TRKG.OFS (tracking offset) so that the TRKG.ERR (tracking error) voltage at TP1 pin 2 becomes 0 V ± 50 mV. 		
		TP1 Pin 6 (FOCS. ERR)	VR6 (FOCS. OFS)	Focus offset 0V ± 50mV	 Adjust VR6 FOCS.OFS (focus offset) so that the FOCS.ERR (focus error) voltage at TP1 pin 6 becomes 0 V ± 50 mV. 		
		TP1 Pin 1 (RF. OUT PUT)	VR2 (RF. OFS)	RF offset 100mV ± 50mV	 Adjust VR2 RF.OFS (RF offset) so that the RF output voltage at TP1 pin 1 becomes 100mV ± 50 mV. 		
					Note: When adjusting the tracking offset, always perform "6. Tracking Balance Adjustment."		
2	RF level adjustn	nent	1	1	1		
		TP1 Pin1 (RF OUT PUT)	VR1 (Laser power)	$1.8V \pm 0.1V$	 Put unit in the test mode (see page 31). Connect the oscilloscope to TP1 pin 1 (RF output), play the test disc, and measure the P-P voltage of the RF waveform. Adjust VR1 (Laser power) so that the voltage is 1.8V ± 0.1V 		
3	LD (laser diode)	power chec	k				
				Less than 0.13mW	 Put unit in the test mode (see page 31). Press the TRACK FWD (D) key to turn ON the laser diode. Place the sensor of the optical power meter directly above the objective lens and confirm that LD power does not exceed 0.13mW. 		

Step No.	Oscilloscope Setting V H		Test Points	Adjusting Check ite		Adjustment procedure
					specifications	
4	Focus lo	ock and s	pindle lock c	heck		•
						 Set the test disc. Put unit in the test mode (see page 31). Press the MANUAL SEARCH FWD (▷▷) key to move the pickup to the center of the disc.
	V 0.5V / div	H 100 msec/ div	TP1 pin1 (RF output)		RF signal is output Forward (clockwise) rotation	 Observe the output of TP1 pin 1 (RF output) on the oscilloscope. Confirm that the RF signal is output after the TRACK FWD (▷▷) key is pressed. Press the PLAY (▷) key and confirm that the disc rotates at constant speed (approx. 30 rpm near center of disc) in the forward (clockwise) direction; disc may not run away or rotate counterclockwise.
5	Grating	adjustn	nent (1)			
	Clamp ho		Fig. 9	Remove the disc tray before beginning this adjustment. Removal of the disc tray Press the rear edge of the rack, (*1) marked in Fig. 9-1, while pulling the disc tray out to the position where it catches, illustrated in Fig. 9-2. The whole the rear edge of rack (A) is pressed, first the disk clamp is released. If you continue pressing after it has been released completely, the disk tray is ejected. While pulling the clamp holder sepected. While pulling the clamp holder indicated by in the left hand and pull it outward. Take care not to allow the φ 4 steel ball to fall (we recommend holding the ball in place with the left index finger while extracting the tray.)		
			Fig. 9-	2		

Step No.	Oscilloscope Setting V H	Test Points	Adjusting Points	Check items / Adjustment specifications	Adjustment procedure
	Spacer —	Fig. 9	9-3	•	
	Clamp :	retainer Fig. 9	Clamper		
	Screwdriver Pickup Disc table	Fig. S	-5		 Put unit in the test mode (see page 31). Press the MANUAL SEARCH FWD (▷▷) key to move the pickup to the vicinity of what would be the center of the disc. Position the pickup so its grating adjusting screw is visible through the elongated hole on the spindle motor side of the servo mechanism base plate. As shown in Fig. 9-5, insert a (slotted) ⊕ screwdriver from the rear of the mechanism and check that the grating adjusting screw can be rotated. Mount the test disc; be sure to insert a 3-5 mm spacer (if no spacer is available, use a hex wrench) between the clamp holder and clamp retainer, as shown in Fig. 9-3. Confirm that the clamper and the clamp retainer are not contacting one another (Fig. 9-4). Press the TRACK FWD (▷▷)
	Pin 2 (TRKE Pin 4 (G	RR) 0-1397 0.001	u.F.	3	and the PLAY (D) keys sequentially to close the focus and spindle servos (do not close the tracking servo). Insert a 4 kHz-cutoff low pass filter between the oscilloscope and TP1 pins 2 (TRKG.ERR) and 4 (GND) as shown in Fig. 9-6 and observe the waveform of TP1 pin 2 (tracking error) on the oscilloscope.

v 0.5V/ div	н 5ms/ div	TP1 Pin 2	Points	specifications				
					Adjustment procedure			
		TRKG. ERR	Grating adjusting screw Grating adjusting screw	Null point - Max. amplitude	 Turn the grating adjusting screw with the ⊖ screwdriver to find the null point (see Photo 9-1). Next, slowly turn the ⊖ screwdriver COUNTERCLOCKWISE and adjust to the point where the waveform (tracking error signal) first achieves its maximum amplitude (see Photo 9-3). 			
					Note: Avoid applying pressure to the ⊖ screwdriver while adjusting the screw. Doing so causes the pickup to move inward, making adjustment more difficult.			
					 Lastly, remove the low pass filter and confirm that the tracking error signal p-p voltage does not greatly vary when the pickup is moved to the inner-most and outer-most tracks of the disc. If the levels diverge by ± 10% or more, re-adjust the maximum error amplitude point by turn the grating 			
	Bear		Re-mount the disc tray according to the following procedure when the grating adjustment is complete. 1. Remove the disc and the spacer. 2. While lifting the clamp holder [marked B in Fig. 9-2] with the right hand, hold the tray in the left hand as indicated by C and slide the slide base into the hard resin fittings on the loading base as shown in Fig. 9-7 to re-insert the disc tray. At this time, be sure to hold the steel ball in place with the index finger of the left hand. Also, be careful that the front panel is not damaged by the					
				slide base and bearing of the steel ball's bearing (in the slide base) coming into contact with the panel. 3. Insert the slide base so that it fits into the two hard resin fittings at the rear of the loading base (see Fig. 9-8). 4. Insert the tray tightly.				
		Bear	Bearing Fig. 9-	Loading base Slide base Bearing Fig. 9-7	Loading base Slide base Bearing Fig. 9-7			

DAC BOARD ASSEMBLY

● The DAC BOARD ASSEMBLY is used the PD-5100/HEM and HB types only.

VRTB6HS104

RD1/4PM DDDJ

SEMICONDUCTORS

VR701,VR702

R701 - R706

Semi-fixed (100k Ω)

<u>Mark</u>	Symbol & Description	Part No.	
**	IC701,IC702	PCM56P	
CAPA	CITORS		
Mark	Symbol & Description	Part No.	_
	C701 - C708	CEAS330M16	
RESIS	TORS		
Mark	Symbol & Description	Part No.	

1. RESISTORS : Indicated in Ω , 1/4W, 1/6W and 1/8W, \pm 5% tolerance

unless otherwise noted k; k Ω , M; M Ω , (F); $\pm 1\%$, (G); $\pm 2\%$, (K); $\pm 10\%$, (M): $\pm 20\%$ tolerance.

2. CAPACITORS :

Indicated in capacity (μ F) /voltage (V) unless otherwise noted p; pF. Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE, CURRENT: ; DC vortage (v) at no input signal.

4. OTHERS :

⇒ ; Signal route.

② : Adjusting point.

The A mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

**marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.


5. SWITCHES: (The underlined indicates the switch position) MAIN BOARD ASSEMBLY S1: TEST MODE FUNCTION BOARD ASSEMBLY S201 : OPEN/CLOSE S202 : PLAY S203: PROGRAM MEMORY S204: RANDOM PLAY S205 : TRACK SEARCH (H4) S206 : PAUSE S207: MANUAL SEARCH (◄◄) S208 : TIME S209 : TRACK SEARCH (▶►) S210 : STOP S211 : MANUAL SEARCH (▶▶) S212: REPEAT S213:1 S214:4 S215:7 S216:0 (TRACK NO.) S217:2 S218:5 S219:8 S220 : EDIT S221:3 S222:6 (TRACK NO.) S223:9 TRANSFORMER BOARD ASSEMBLY S301 : POWER ON - OFF MISCELLANEOUS S101: INSIDE S102 : CLAMP OPEN - CLAMP

MAIN BOARD ASSEMBLY (PWZ1421)

The main board assembly (PWZ1421) is the same as the main board assemble (PWZ1419) with the exception of the following sections.

		Part	Remarks	
Mark	Symbol & Description	PWZ1419	PWZ1421	Nemark
-	C60 C61,C63 C62 C162 C65 C75,C76 C77,C78 C71,C72 C79,C80 IC18 IC30 – IC32 IC24 Q26 Q27 R77 R156,R157 R158 R79,R80 R97,R98 R101,R102 R109,R110	CEAS330M16 CQMA103K50 CEAS101M10 CEAS101M10 CQMA561J50 CQMA681J50 CEAS220M50 CEAS330M16 LC7881 - B M5218P 2SC1740S RD1/6PM222J RD1/6PM752J RD1/6PM752J RD1/6PM103J	CCCCH100D50 CQMA102K50 CQMA332J50 ICP-N10 2SC3732 RD1/6PM103J RD1/6PM102J RD1/6PM102J RD1/6PM182J RD1/6PM822J	

10. REMOTE CONTROL UNIT



NOTES:

- Parts without part number cannot be supplied.
- The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★. ★★ GENERALLY MOVES FASTER THAN ★
- This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.
- ●Parts marked by "®" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

Parts List of Remote control unit

Mark	No.	Part No.	Description
	1	PNW1159	Case (T)
	2	PNW1160	Case (B)
	3	PNW1161	Cover
	4	PAM1077	Filter
	- 5	PWW1022	Remote control unit

11. FOR KC. HEM. AND HB TYPES

NOTES:

• Parts without part number cannot be supplied.

- ●Parts marked by "®" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- •The ∆mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.

** GENERALLY MOVES FASTER THAN *

This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.

- When ordering resistors, first convert resistance values into code form as shown in the following examples.
- Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).


11.1 CONTRAST OF MISCELLANEOUS PARTS


The PD-5100/KC, HEM AND HB types are the same as the PD-5100/KU type with the exception of the following sections.

			Part	No.		
Mark	Symbol & Description	PD-5100 /KU type	PD-5100 /KC type	PD-5100 /HEM type	PD-5100 ∕HB type	Remarks
♠♠♠♠♠★	Main board assembly DAC board assembly AC power cord Power transformer (AC120V) Power transformer (AC220V/240V)	PWZ1419 PDG1015 PTT1054	PWZ1419 PDG1015 PTT1054	PWZ1421 Non supply PDG1003 PTT1055	PWZ1421 Non supply PDG1004 PTT1055	
	Packing case Operating instructions (English) Operating instructions (English/French)	PHG1179 PRB1045	PHG1194 PRE1055	PHG1194 PRE1055	PHG1194 PRB1045	For packing
Δ	Operating instructions (German / Italian / Spanish / Portuguese / Swedish / Dutch) Strain relief FL filter A FL filter C	CM-22C PAM1230	CM-22C PAM1230	PRF1011 CM-22B PAM1231	CM-22B PAM1231	


http://www.ManualsCenter.com

11.2 SCHEMATIC DIAGRAM








6





http://www.ManualsCenter.com











11.3 P.C. BOARD PATTERN


P.C. Boards Pattern of PD - 5100/HEM, HB types are the same connections as the PD-5100/KU type.

Refer to PD - 5100/KU type.

LINE VOLTAGE SELECTION FOR HEM AND HB TYPES

- 1. Disconnect the AC power cord.
- 2. Remove the bonnet.
- 3. Change the position of the jumper (A) as follows (Refer to the transformer board assembly).


Voltage	Jumper (A) position
220V	1
240V	2





TRANSFORMER BOARD ASSEMBLY


http://www.ManualsCenter.com











12. FOR PD - 4100/KU, KC, HEM AND HB TYPES

NOTES

Parts without part number cannot be supplied.

- Parts marked by "®" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
 The ∆mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing,
- be sure to use parts of identical designation.

 ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.

** GENERALLY MOVES FASTER THAN *

This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.

When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5 %, and K = 10 %).

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors). $5.62k \Omega \rightarrow 562 \times 10^1 \rightarrow 5621$ RN1/4SR[5]6[2]1]F

12.1 CONTRAST OF MISCELLANEOUS PARTS

The PD -4100/KU, KC, HEM and HB types are the same as the PD -5100/KU type with the exception of the following sections.

				Part No.			
Mark	Symbol & Description	PD - 5100 /KU type	PD - 4100 /KU type	PD - 4100 /KC type	PD - 4100 /HEM type	PD - 4100 /HB type	Remarks
•	Main board assembly Headphone board assembly Function board assembly Headphone knob	PWZ1419 Non supply PWZ1425 PAC1208	PWZ1418 PWZ1422	PWZ1418 PWZ1422	PWZ1440 PWZ1422	PWZ1440 PWZ1422	
	Button A Button B Button B (O/C) Button A (O/C) Window B	PAC1247 PAC1248 PAC1250 PAM1175	PAC1245	PAC1245	PAC1245	PAC1245	
	Window A Connection cord with mini plug	: : : : :	PAM1173 PDE-319	PAM1173 PDE-319	PAM1173 PDE-319	PAM1173 PDE-319	
	Packing case Name plate A (tray)	PHG1179	PHG1178 PNW1352	PHG1193 PNW1352	PHG1193	PHG1193	For packing
	Name plate B (tray) Function panel A Function panel B Insulator Operating instructions (English)	PNW1358 PNW1356 PNW1376 PRB1045	PNW1355 PRB1044	PNW1355	PNW1358 PNW1355	PNW1358 PNW1355 PRB1044	
	Operating instructions (English/French) Operating instructions (Garman/Italian/Spanish /Portuguese/Swedish/Dutch)	• • • • •	• • • • •	PRE1054	PRE1054 PRF1010		
Δ *	Power transformer (AC120V) Power transformer (AC220V/240V) Remote control unit	PTT1054	PTT1046	PTT1046	PTT1065	PTT1065	
	Foot assembly	PWW1022	REC-369	REC-36ə	REC-369	REC - 369	
Δ	in relief	CM-22C PAM1230	CM-22C PAM1230	CM-22C PAM1230	CM-22B	CM-22B	Į
Δ	FL filter C AC power cord	PDG1015	PDG1015	PDG1015	I AM1231 PDG1008	PAM1231 PDG1009	

MAIN BOARD ASSEMBLY (PWZ1418 and PWZ1440)

The main board assembly (PWZ1418) and (PWZ1440) are the same as the main board assembly (PWZ1419) with the exception of the following sections.

Mark	Symbol & Description	T	Part No.		
	Cymbol & Description	PWZ1419	PWZ1418	PWZ1440	Remarks
	C59 C61,C63 C81,C82 C87 C89,C90	CEAS330M16 CQMA103K50 CEAS101M50 CEAS220M50	CKCYF103Z50 CCCCH300J50	CEAS330M16 CKCYF103Z50	
	C65 C62 C91 C95,C96 C104,C105	CEAS101M10 CEAS101M10 	CEAS101M10 CKCYF103Z50	CEAS471M10 CKCYF103Z50 CCCCH270J50	
	C106,C107 C75,C76 C77,C78 C147 C119	CEAS471M16 CQMA561J50 CQMA681J50 CKCYF103Z50	CQMA471J50 CQMA821J50 CEAS220M50	CQMA471J50 CQMA821J50 CKCYF103Z50 CEAS220M50	
*	C121,C122 C301 - C303 D5 - D9 D11	CQSA102J50 CKCYF103Z50 1SR139 - 100 MTZ27B (MTZ27C)	CQMA102K50	CQMA102K50	
* ** **	D12 D17 - D19 IC18 IC13	MTZ5.1B (MTZ5.1C) LC7881-B NJM78L12A	1SS254 LC7881-C	1SS254 LC7881 - C	
** ** ** **	IC14 IC28 IC30 – IC32 Q18 Q27	NJM79L12A PD0034 2SA1048 2SC1740S		PD0034 ICP-N10	
	R76 R105,R106 R115,R116 R117 R118	RD1/6PM511J RD1/6PM511J	RD1/6PM471J RD1/6PM102J RD1/6PM274J RD1/6PM102J	RD1/6PM271J RD1/6PM102J ••••• RD1/6PM274J RD1/6PM102J	
	R120,R77 R121 R127,R128 R153 R154	RD1/6PM222J RD1/6PM472J RD1/6PM223J	RD1/6PM362J RD1/6PM362J RD1/6PM391J	RD1/6PM362J RD1/6PM362J RD1/6PM391J	
	R69 R97,R98 R101,R102 R109,R110 R134	RD1/6PM221J RD1/6PM752J RD1/6PM752J RD1/6PM103J RD1/6PM391J	RD1/6PM822J RD1/6PM472J RD1/6PM822J	RD1/6PM221J RD1/6PM822J RD1/6PM472J RD1/6PM822J RD1/6PM391J	
*	X2 Ciystal resonator X3 Crystal resonator	PSS-012	PSS-012	PSS-012	

FUNCTION BOARD ASSEMBLY (PWZ1422)

The function board assembly (PWZ1422) is the same as the function board assembly (PWZ1425) with the exception of the following sections.

Mark	Symbol & Description	Pa		
Symbol & Description	PWZ1425	PWZ1422	Remarks	
**	D204 - D206 S203,S213 - S219,S221 - S223 Tact switch	1SS254 PSG-065		
*	V201 Fluorescent indicator tube IR sensor unit R205	PEL1019 GP1U50V	PEL1018 RD1/6PM222J	

12.2 EXPLODED VIEWS AND PARTS LIST

NOTES:

- Parts without part number cannot be supplied.
- ●The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- ●For your parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.

** GENERALLY MOVES FASTER THAN *


This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.

- ●Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- ullet The mechanism section is the same as the PD 5100/KU type, please refer to pages 12 14.

Parts List of Exterior


Mark No.	Part No.	Description	Mark No. Part No.	Description
1	CM-22C	Strain relief	101	Under base
△ 2	PDG1015	AC power cord	102	onder base
△ ★ 3	PTT1046	Power transformer	103	Rear base
		(AC120V)	104	Angle
4	PBA1001	Screw	105	Panel angle
5	REC-369	Foot assembly	106	Board angle
6	PYY1062	Bonnet	107	Switch angle
7	PAC1244	Button A (PLAY)	108	Slide guide
8	PAC1246	Button A (POWER)	109	Mechanism support
9		• • • •	110	P.Plate holder
10		• • • •	111	Loading base assembly
11	PAC1245	Button A (O/C)	112	Tray assembly
12	PAM1230	FL filter A	113	• • • • •
13	PAM1173	Window A	114	Headphone name plate
14	PNW1355	Function panel A	115	Name plate
15	PNW1352	Name plate A (tray)	116	SW joint
16	BBZ30P060FMC	Screw	117	
17	BBZ30P080FZK	Screw	118	Transformer board
18	BBZ30P120FMC	Screw		assembly
19	BBZ30P230FMC	Screw		,
20	FBT40P080FZK	Screw		
21	IBZ40P080FCC	Screw		•
22	PMZ30P060FCU	Screw		
② 23	PWZ1418	Main board assembly		•
② 24	PWZ1422	Function board assebmly	•	•
25	PYY1063	Servo mechanism assembly		





PD-4100/KU,KC,HEM,HB

12.3 SCHEMATIC DIAGRAM FOR HEM AND HB TYPES




12.4 LINE VOLTAGE SELECTION FOR HEM AND HB TYPES


- 1. Disconnect the AC power cord
- 2. Remove the bonnet.
- 3. Change the position of the jumper (A) as follows


Voltage	Jumper A position
22 0V	1
240V	2

TRANSFORMER BOARD ASSEMBLY



 		to the Martin Control of the State of the St	en e	and the second second





12.6 P.C. BOARD PATTERN

P.C. Boards Pattern of PD -4100/KU, KC, HEM, HB types are the same connections as the PD -5100/KU type. Refer to PD -5100/KU type.

TRANSFORMER BOARD ASSEMBLY

O

A


POWER


TRANSFORMER


S301


POWER

MAIN BOARD ASSEMBLY (PWZ1418) FOR KU, KC types MAIN BOARD ASSEMBLY (PWZ1440) FOR HEM, HB types









13. FOR PD - 5100 - S/HEM, PD - 4100 - S/HEM AND HB TYPES

• Parts without part number cannot be supplied.

●The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

●For your Parts Stock Control, the fast moving items are indicated with the marks ★★ and ★.

** GENERALLY MOVES FASTER THAN *

- This classification shall be adjusted by each distributor because it depends on model number, temperature, humidity, etc.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

13.1 CONTRAST OF MISCELLANEOUS PARTS

●FOR PD - 5100 - S/HEM TYPE

The PD -5100 - S /HEM type is the same as the PD -5100 /HEM type with the exception of the following sections.

		Part	Remarks	
Mark Symbol & Description	PD - 5100/HEM type	PD - 5100 - S/HEM type	Hemarks	
	Headphone knob Button A (PLAY) Button A (POWER) Button A Button B	PAC1208 PAC1244 PAC1246 PAC1247 PAC1248	PAC1271 PAC1279 PAC1281 PAC1282 PAC1283	
	Button B (O/C) Packing case Function panel B Name plate B (tray) Bonnet	PAC1250 PHG1194 PNW1356 PNW1358 PYY1062	PAC1284 PHG1204 PNW1379 PNW1398 PYY1068	For packing
	Headphone name plate Earth plate	Non supply	Non supply Non supply	

13.2 CONTRAST OF MISCELLANEOUS PARTS FOR PD-4100-S/HEM AND HB TYPES

The PD-4100-S/HEM and HB types are as same as the PD-4100/HEM type with the exception of the following sections.

Mark	Symbol & Description				
		PD - 4100 /HEM type	PD - 4100 - S /HEM type	PD - 4100 - S /HB type	Remarks
Δ	Button A (PLAY) Button A (O/C) Button A (POWER) Window A Packing case Function panel A Name plate B (tray) AC power cord Operating instructions (English) Operating instructions (English/French) Operating instructions (German/Italian/Spanish, Dutch/Portuguese/Swedish) Headphone name plate Earth plate Bonnet	PAC1244 PAC1245 PAC1246 PAM1173 PHG1193 PNW1355 PNW1358 PDG1008 PRE1054 PRF1010 Non supply PYY1062	PAC1279 PAC1280 PAC1281 PAM1218 PHG1207 PNW1377 PNW1398 PDG1008 PRE1054 PRF1010 Non supply Non supply PYY1068	PAC1279 PAC1280 PAC1281 PAM1218 PHG1207 PNW1377 PNW1398 PDG1009 PRB1044 Non supply Non supply PYY1068	

- 1. RESISTORS: Indicated in Ω , 1/4W, 1/6W and 1/8W, $\pm 5\%$ tolerance unless otherwise noted k; k Ω , M; M Ω , (F); $\pm 1\%$, (G); $\pm 2\%$, (K); $\pm 10\%$, (M); $\pm 20\%$ tolerance.
- 2. CAPACITORS: Indicated in capacity (µF) /voltage (V) unless otherwise noted p; pF. Indication without voltage is 50V except electrolytic capacitor.
- 3. VOLTAGE, CURRENT: ; DC voltage (V) at no input signal.
- 4. OTHERS:

: Signal route. (a); Adjusting point.

The A mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation. marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

5. SWITCHES: (The underlined indicates the switch positio: MAIN BOARD ASSEMBLY S1: TEST MODE FUNCTION BOARD ASSEMBLY S201 : OPEN/CLOSE \$202 : PLAY S203 : PROGRAM MEMORY S204 : RANDOM PLAY S205: TRACK SEARCH (H4) S206 : PAUSE S207: MANUAL SEARCH (◄◄) S208 : TIME S209: TRACK SEARCH (>>) S210: STOP S211: MANUAL SEARCH (▶▶) S212: REPEAT S213:1 S214:4 S215:7 S216:0 (TRACK NO.) S217:2 S218:5 S219:8 S220 : EDIT S221:3 (TRACK NO.) S222:6 S223:9

TRANSFORMER BOARD ASSEMBLY

S301 : POWER ON - OFF

MISCELLANEOUS S101 : INSIDE

S102 : CLAMP OPEN - CLAMP

External appearance of transistors and ICs

